



HYDRANT METER REQUIREMENTS


WITH AIR GAP



WITH (RPBA) ATTACHED TO HYDRANT METER



WITH (RPBA) ATTACHED TO WATER TRUCK



NOTES:

1. ANY WATER TRUCKS OR TANKS THAT ARE FILLED FROM A POTABLE WATER SUPPLY SUCH AS A FIRE HYDRANT OR WATER HOSE SHALL BE FITTED WITH A REDUCED PRESSURE BACKFLOW ASSEMBLY (RPBA) OR BE FILLED THROUGH AN AIR GAP, WITH NO WAY TO BYPASS.
2. ALL HOSES USED TO FILL TANKS SHALL HAVE NOT BEEN USED TO CONVEY ANY SUBSTANCE OTHER THAN POTABLE WATER.
3. IF CONTRACTOR USES THEIR OWN APPROVED (RPBA) THEY MUST CALL IN AND UPDATE THE BACKFLOW PREVENTER INFO SO IT CAN BE ATTACHED TO THE HYDRANT METER THAT WAS ISSUED OUT. THE BACKFLOW PREVENTER INFO WILL BE REMOVED FROM THE HYDRANT METER ONCE THE METER IS RETURNED.
4. ONCE INSTALLED ALL BACKFLOW PREVENTERS ARE REQUIRED TO BE TESTED ANNUALLY PER CODE - IDAPA 58.01.08.552.06.e / 24.05.01.650 (APPENDIX A.)
5. TEST REPORTS CAN BE EMAILED TO BACKFLOW@MERIDIANCITY.ORG